



Operating Instructions for Hydraulic Crimp Tool

NSN F1 5120-99-891-9831

D36 op1



Select appropriate die set for terminal to be crimped.
Open latch head and insert dies into lower and upper die holder.
Close the latched head

D36 op2



Insert the connector between the dies and pump the moving handle until an audible 'click' is heard and dies are closed.

D36 op3



Press the trigger release trigger.
Open the latch head and remove crimped connector.